



TRACTORS AUSTRALIA

Tractors Australia

Unit 1/28-30 Jack Williams Dr Penrith NSW 2750

PO Box 610 Emu Plains NSW 2750

P : 02 4722 2299 | F : 02 4722 2263

HOW TO MEASURE A TOOTH ACCURATELY

When ordering a tooth for your machine we'll ask a number of questions to make sure we get the right tooth for your machine. It helps to have your answers ready before you contact us.

Here's an example of the questions we'll ask and a guide on how to find the answers:

1. Remove tooth from bucket.
2. Measure from very outside from the left to measure across to the very inside of the right (or the internal wall on the right hand side). Please see photo.
3. Identify if the tooth is square across the top and down the sides. Some brands are curved on the sides.
4. Identify the pins. Are they vertical or horizontal? Are they round pins with retainer or square pins with rubber locks?
5. **Email or phone** through this information to insidesales@trnsw.com.au or ph 4722 2299. A template is attached for your reference.

